



SKC[®]

Technical Note

Leak Testing the Dräger accuro Bellows Pump



Dräger accuro Bellows Pump Cat. No. 800-64000

Leak Test Procedure for the Dräger[®] Accuro Bellows Pump

1. Insert unopened Dräger Detector Tube[®] into bellows pump.
2. Squeeze bellows pump completely and release.
3. Pump is adequately leak proof if the end-of-stroke indicator has not appeared (i.e. popped up) within fifteen (15) minutes.

Quick Leak Test Procedure

1. Insert unopened Dräger Detector Tube into bellows pump.
2. Squeeze bellows pump completely and release.
3. After releasing, the position of the pump body should not change within one minute. If you see movement of the bellows after the initial release, the pump should be checked using a time interval of fifteen (15) minutes.