



## Formaldehyde — OSHA 52

The previous OSHA method for formaldehyde sampling involved a bubbler. Sampling with bubblers is often inconvenient and OSHA began evaluating sorbent sampling methods. Since both acrolein and formaldehyde are frequently found together, OSHA Method 52 was developed to produce a common sorbent tube sampling method for each.

### Required Equipment:

1. An **air sampling pump** capable of sampling at the recommended flow rate with the sampling medium in line, such as:
  - SKC 224-XR Series Universal Sampler with Low Flow Holder Cat. No. 224-26-01 and Protective Cover Cat. No. 224-29A for STEL or 224-29B for TWA
  - SKC AirChek® 2000 Sampler with Constant Pressure Controller Cat. No. 224-26-CPC, Low Flow Holder Cat. No. 224-26-01, and Protective Cover Cat. No. 224-29A for STEL or 224-29B for TWA
  - SKC 210 Series Pocket Pump® Sampler with Tube Holder Cat. No. 222-3-1 for STEL or 222-2L-1 for TWA
2. An **air flow calibrator**, such as:
  - SKC UltraFlo® Calibrator Cat. No. 709
  - DC-Lite Flowmeter Cat. No. 717-01
3. SKC **Sorbent Tube** Cat. No. 226-54 for STEL or 226-117 for TWA

### Optional Equipment:

1. SKC **Tube Breaker** Cat. No. 222-3-50

### SKC Application Guides:

1. Sampling Train—Sorbent Sample Tubes, #1168
2. Calibrating a Pump Using a Film Flowmeter, #1163
3. Calibrating a Pump Using an Electronic Calibrator, #1366

	TWA	STEL
Flow Rate	100 ml/min	200 ml/min
Sample Time	4 hours	15 minutes
Air Volume	24 L	3 L
OSHA PEL	0.75 ppm	2 ppm
<i>(per 29 CFR 1910.1000)</i>		

### Sampling and Analysis:

1. To set up a sorbent tube sampling train, break open both ends of a sorbent tube using the optional SKC sorbent tube breaker. Insert the sorbent tube into the rubber sleeve of the adjustable low flow holder or tube holder. The arrow on the sorbent tube indicates air flow and should point toward the tube holder and pump. In the absence of an arrow, insert the end of the tube with the smallest sorbent section (backup section) into the tube holder. Connect the

loose end of the flexible tubing to the pump inlet. Request SKC Application Guide #1168 for more information on preparing sorbent tube sampling trains.

2. For calibrating the pump, use the sampling train described above except connect the sorbent tube inlet to the calibrator with a piece of flexible tubing. Calibrate the pump flow rate to the rate specified in the method. When calibration has been completed, remove the sorbent tube, cap it with the end caps provided, and save it for recalibration at the end of sampling. Request SKC Application Guide #1366 or #1163 for more information on calibrating a pump.

3. For sampling, set up a sampling train as above except use a new sorbent tube and do not break off the ends until ready to sample. The larger section of sorbent should be facing away from the pump. Place the protective cover over the sorbent tube. Attach the clip on the protective cover to a worker's clothing near the breathing zone and the pump to the worker's belt. The sorbent tube should remain in a vertical position during sampling. Turn the pump on.

4. Sample at an accurately known flow rate for the recommended period of time.

5. At the end of the sampling period, turn the pump off and note the ending time. Remove the sorbent tube, seal the ends of the tube with the end caps provided, and record any pertinent sampling information.

6. Calibrate the pump with the representative sampling media in line to verify that the flow has not changed by more than 5%.

7. Submit field blanks from the same lot number as the sample tubes. Field blanks should be subjected to exactly the same handling as the samples (open, seal, and transport) except that no air is drawn through them.

8. Pack sample sorbent tubes, field blanks, and all pertinent information securely for shipment to a laboratory for analysis.

### Storage:

Store samples at room or refrigerated temperature. Analyze sample within 21 days of collection.

### Analyzing Method:

Gas chromatography - Nitrogen-phosphorus detector (GC-NPD)

Copyright 1992 - 2002

*Notice: This publication is intended for general information only and should not be used as a substitute for reviewing applicable government regulations, equipment operating instructions, or legal standards. The information contained in this document should not be construed as legal advice or opinion nor as a final authority on legal or regulatory procedures.*