



Chemical Fact File®

Ethylene oxide by portable GC — NIOSH 3702

NIOSH Method 3702 complements NIOSH 1614 which uses sorbent tubes and GC analysis. The working range of NIOSH 3702 is 0.001 to 1000 ppm in non-complex atmospheres. Freon® 12, carbon dioxide, and alcohol do not interfere. Compounds with similar retention times under the same GC conditions may interfere.

Required Equipment:

1. An **air sampling pump** capable of sampling at the recommended flow rate with the sampling medium in line, such as:
 - SKC **Universal Sampler**
 - SKC **222 Series Low Flow Sampler**
2. An **air flow calibrator**, such as:
 - Defender Primary Standard Calibrator Cat. No. 717 Series
3. SKC **Sampling Bag** Cat. No. 232 Series
4. SKC **PTFE Tubing** Cat. No. 231-9-21 or 231-9-23

Optional Equipment:

1. SKC **Septum** Cat. No. 232-01-RS

SKC Application Guides:

1. Sampling Train — Air Sample Bags, #1167
2. Calibrating a Pump Using an Electronic Calibrator, #1366

	TWA	Ceiling
Flow Rate	varies	varies
Sample Time	varies	varies
Air Volume	varies	varies
NIOSH REL	0.1 ppm	5 ppm/10 min
<i>(NIOSH Manual of Analytical Methods [NMAM], Fourth Edition, 8/15/94)</i>		

Sampling and Analysis:

1. Calibrate the pump to the desired flow rate. *Request SKC Application Guide #1366 for more information on calibrating a pump.*

2. For sampling, attach a piece of tubing to the hose/valve fitting of the bag. Connect the other end of the tubing to the outlet fitting of the pump. Place the pump in the work area to be monitored and open the valve on the bag. *Request SKC Application Guide #1167 for further information on setting up a sampling train using air sample bags.*

3. Sample at an accurately known flow rate for the recommended period of time.

4. At the end of the sampling period, turn off the pump, close the valve on the bag by turning it clockwise, and note the ending time. Remove the bag and record any pertinent sampling information.

5. Calibrate the pump with the representative sampling media in line to verify that the flow has not changed by more than 5%.

6. The sample can be either analyzed directly from the bag using a portable gas chromatograph or sent to a laboratory for analysis. Sample bags sent out for analysis should be packed loosely and padded to minimize the danger of being punctured during shipment. All pertinent sampling information should be included. Do not ship the bags by air unless they are stored in a pressurized cabin. Shipments of filled sample bags must comply with regulations concerning hazardous materials.

Storage:

Store samples at room temperature. Analyze sample within 24 hours of collection.

Analyzing Method:

Portable gas chromatography with photo-ionization detector (P GC-PID)

Copyright 1992 - 2010

Notice: This publication is intended for general information only and should not be used as a substitute for reviewing applicable government regulations, equipment operating instructions, or legal standards. The information contained in this document should not be construed as legal advice or opinion nor as a final authority on legal or regulatory procedures.

Publication 1031 Rev 1006

SKC Inc. 724-941-9701

SKC South 434-352-7149

SKC Gulf Coast 281-859-8050

SKC West 714-992-2780

www.skcinc.com