



863 Valley View Rd, Eighty Four, PA 15330  
724-941-9701  
skcinc.com

## **Skin SWYPE for Aliphatic Amines**

### **Cat. No. 769-1035**

### **Operating Instructions**

***Limited shelf-life:*** Check expiration date on packaging.

1. Wipe the skin with the cloth portion of the Skin SWYPE pad.
2. Pour ¼ inch of Developing Solution for Aliphatic Amines Cat. No. 769-1065 into the small cup provided.
3. Put the Skin SWYPE pad in the cup, cloth end down and color detection strip up. The developing solution will wick up to the color detection strip and a color change will occur if contamination is present.
4. Allow 3 minutes for color to develop on the strip. A fuchsia color indicates that aliphatic amines may be present. This color reaction relies on detecting the alkaline pH of aliphatic amines.

#### ***SKC Limited Warranty and Return Policy***

*SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to [skcinc.com/warranty](http://skcinc.com/warranty).*

Form 37543 Rev 241107