

# Instructions

## For

### Decontamination Solutions

#### **Aromatic Amines**

##### Cleaning/Decontamination

1. Wet area thoroughly with cleaning solution\*. Use an abrasive pad if necessary to enhance penetration. Do not rinse before applying decontamination solution.
2. Spray the area with decontamination solution and allow it to react for at least 5 minutes. Rinse with water.
3. Recheck the area with a Surface SWYPEÔ to verify decontamination is complete.
4. To decontaminate tools, mix 1 part decontamination solution with 3 parts cleaning solution in a closed container. Let tools soak for approximately 5 minutes and rinse with water. Recheck with Surface SWYPEÔ to verify decontamination is complete.

\* The cleaning solution is the same as the developing solution for Aromatic Amines.

#### **Isocyanates**

##### Cleaning/Decontamination

1. Wet area thoroughly with decontamination solution. Use an abrasive pad if necessary to enhance penetration.
2. Allow the solution to react for at least 5 minutes. Rinse with water.
3. Recheck the area with a Surface SWYPEÔ to verify decontamination is complete.
4. To decontaminate tools, soak in decontamination solutions for at least 5 minutes and rinse with water. Recheck with Surface SWYPEÔ to verify decontamination is complete.