



863 Valley View Rd, Eighty Four, PA 15330
724-941-9701
skcinc.com

Skin SWYPE for Aromatic Isocyanates

Cat. No. 769-1032

Operating Instructions

Limited shelf-life: Check expiration date on packaging.

1. Wipe the skin with the cloth portion of the Skin SWYPE pad.
2. Pour ¼ inch of Developing Solution for Isocyanates Cat. No. 769-1062 into the small cup provided.
3. Put the Skin SWYPE pad in the cup, cloth end down and color detection strip up. The developing solution will wick up to the color detection strip and a color change will occur if contamination is present.
4. Allow 3 minutes for color to develop on the strip. A red-orange color is specific for isocyanates.

SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to skcinc.com/warranty.

Form 37541 Rev 241106